



UNLEASH THE POWER

U.P.Tv5 INSTALLER

USER GUIDE

BY ARCHIE120

REVISED
6:38 pm, Sep 14, 2008

WARNING

BEFORE USING THIS U.P.T. PROGRAM, YOU MUST MAKE SURE THAT YOU HAVE REMOVED ANY CUSTOM THEMES OR CUSTOM PRX MODULES THAT ARE FLASHED TO **FLASH 0** AND RETURN YOUR SYSTEM TO IT'S DEFAULT CFW STATE, THIS INCLUDES ANY PTF THEMES THAT YOU HAVE INSTALLED, AS FAILING TO DO THIS CAN HAVE VERY UNWANTED SIDE EFFECTS WHEN USING YOUR PANDORA SETUP.

REMOVE ALL CUSTOM PTF THEMES FROM THE SYSTEM BEFORE INSTALLING.

HOW TO CREATE YOUR U.P.T. MAGIC MEMORY STICK (PLEASE READ ALL NOTE'S)

ITEMS REQUIRED:

AN ORIGINAL PRO DUO MEMORY STICK THAT HAS A LEAST 512MB OF FREE SPACE

A **PSP** RUNNING CUSTOM FIRMWARE AND WITH NO THEMES INSTALLED, THIS INCLUDES PTF THEMES (IT IS BEST FOR THE **PSP** TO BE RUNNING A MINIMUM OF 3.40-0E, NOT TESTED ON 3.03) WITH A BATTERY AT LEAST 75% FULL (IDEALLY 100% FULL).

YOU WILL REQUIRE ALL OF THE FOLLOWING EBOOTS

OFFICIAL EBOOT	RENAMED EBOOT	DOWNLOAD
1.50	150.PBP	HERE
3.40	340.PBP	HERE
3.71	371.PBP	HERE
3.80	380.PBP	HERE
3.90	390.PBP	HERE
4.01	401.PBP	HERE
THE FOLLOWING IS NEEDED FOR TIME MACHINE DEPENDING ON WHAT YOU ARE INSTALLING.		
NONE	3.60.PSAR	USER TO LOCATE

METHOD:

NOTE 1:

IN ORDER TO USE DC7 YOU NEED TO INSTALL THE TIME MACHINE IPL FROM STAGE 1 OF THE INSTALLER, INSTALLING THE STANDARD IPL WILL ONLY ALLOW YOU TO BOOT TO ULTIMATE LOADER'S MENU.

NOTE 2:

UPT NOW REQUIRES THE USE OF A **3xx** OR **4xx KERNEL**, IT WILL NOT RUN ON **1.50 KERNEL** DUE TO SOME INTERNAL FUNCTIONS.

NOTE 3:

IF YOU ALREADY OWN A PANDORA BATTERY AND MEMORY STICK WITHOUT THE MULTI-BOOT FUNCTION YOU MUST REMOVE YOUR BATTERY AND PLUG IN THE AC CABLE, BUT THE MEMORY STICK CAN REMAIN INSERTED.

NOTE 4:

IF YOU ARE RUNNING A **PSP** WITH CUSTOM FIRMWARE **3.80M33** OR **3.90M33** INSTALLED YOU WILL HAVE A SLIGHTLY DIFFERENT INSTALL SEQUENCE. THIS SEQUENCE WILL INVOLVE THE COPY AND WRITING OF FILES TO A SPACE IN **FLASH 0** AND **FLASH 2**.

NOTE 5:

U.P.T. INSTALLER NOW HAS AN APPLICATION EMBEDDED THAT WILL ENABLE YOU TO FORMAT A FAKE MEMORY STICK (YOU ARE STILL ADVISED TO USE AN ORIGINAL PRO DUO STICK).

NOTE 6:

U.P.T. INSTALLER NOW HAS AN OPTION EMBEDDED THAT WILL ENABLE YOU TO REMOVE AN OLDER PANDORA/U.P.M.S OR U.P.T. SETUP FROM YOUR STICK WITHOUT HAVING THE NEED TO REFORMAT AND REMOVE THE IPL SETTINGS.

NOTE 7:

U.P.T. INSTALLER NOW HAS A BUILT-IN RANDOM SERIAL NUMBER[©] GENERATOR FOR YOUR PSP's BATTERY, THIS IS VERY USEFUL IF YOU HAVE LOST YOUR EEPROM OR DID NOT MAKE A BACKUP.

NOTE 8:

U.P.T. WILL NOW DISABLE THE BATTERY MENU FOR THE LATEST SLIM & LITE MODELS KNOWN AS TA-085v2 OR LATER.

NOTE 9:

A NEW NAND & ID STORAGE BACKUP HAS BEEN IMPLEMENTED INTO ULTIMATE LOADER.

NOTE 10:

IF USING ANY FIRMWARE VERSION OTHER THAN 3.80M33 & 3.90M33 THERE IS NOW NO NEED TO INSTALL THE FATSMOD.PRX, THE INSTALLER WILL CHECK THE FIRMWARE VERSION YOU ARE USING AND DISPLAY THE APPROPRIATE SPLASH SCREEN.

NOTE 11:

U.P.T. INSTALLER NOW HAS A BUILT-IN DOWNLOAD OPTION FOR ALL REQUIRED EBOOTS FOR YOU TO MAKE YOUR MAGIC MEMORY STICK IF THEY ARE NOT FOUND .

STEPS

1. SWITCH ON YOUR PSP.
2. SCROLL TO THE USB ICON AND CONNECT TO THE COMPUTER.
3. BACK UP THE ENTIRE CONTENTS OF YOUR MEMORY STICK TO A SAFE FOLDER ON YOUR COMPUTER (THIS SO THAT YOU CAN KEEP ANYTHING YOU MAY REQUIRE LATER E.G. MUSIC ETC).
4. DISABLE THE PSP FROM THE COMPUTER.
5. SCROLL TO SYSTEM SETTINGS AND , THEN SCROLL TO FORMAT MEMORY STICK AND PRESS TO FORMAT YOUR MEMORY STICK.
6. AFTER THE MEMORY STICK HAS BEEN FORMATTED SCROLL BACK TO THE USB ICON AND CONNECT TO THE COMPUTER. IF YOU ARE USING A FAKE MEMORY STICK FOLLOW THE NEXT STEPS IF NOT GO TO NUMBER 8.
 - 6.1 IF YOU ARE USING A FAKE MEMORY STICK COPY IN TO THE PSP/GAME FOLDER THE U.P.T. APPLICATION FILE (THIS IS JUST A DRAG AND DROP PROCESS).
 - 6.2 DISCONNECT YOUR PSP FROM THE COMPUTER.
 - 6.3 SCROLL TO THE GAME ICON IN THE XMB AND THEN SCROLL TO THE MEMORY STICK ICON PRESS AND THEN PRESS AGAIN TO RUN THE INSTALLER.
 - 6.4 SCROLL TO THE OPTION THAT SAYS FORMAT & REPARTITION MEMORY STICK AND FORMAT YOUR MEMORY STICK. THIS WILL ALSO CREATE ALL THE NECESSARY FOLDERS NEEDED FOR YOUR MAGIC MEMORY STICK.
 - 6.5 SCROLL TO THE USB ICON AND CONNECT TO THE COMPUTER.
7. COPY ALL THE DOWNLOADED AND RENAMED EBOOTS ON TO THE ROOT OF YOUR MEMORY STICK (THIS IS JUST A DRAG AND DROP PROCESS) IF THEY ARE NOT FOUND DURING THE INSTALL SEQUENCE A SCREEN WILL APPEAR ASKING YOU IF YOU WISH TO DOWNLOAD THE REQUIRED FILE. THE ROOT OF THE MEMORY STICK IS THE VERY FIRST LEVEL THAT YOU SEE WHEN YOU ARE CONNECTED TO THE COMPUTER.
8. OPEN UP THE PSP/GAME FOLDER AND COPY IN TO IT THE U.P.T. APPLICATION FILE (THIS IS JUST A DRAG AND DROP PROCESS).
9. DISCONNECT YOUR PSP FROM THE COMPUTER.
10. SCROLL TO THE GAME ICON IN THE XMB AND THEN SCROLL TO THE MEMORY STICK ICON PRESS AND THEN PRESS AGAIN TO RUN THE INSTALLER.
11. **IF YOU ARE RUNNING FIRMWARE 3.80M33 OR 3.90M33 FOLLOW THE STEPS BELOW IF NOT JUST PRESS AGAIN.**
 IF RUNNING **3.80M33** OR **3.90M33** THE SOFTWARE WILL DETECT THIS AND A DIFFERENT SCREEN WILL APPEAR (**THIS WILL ENABLE YOU TO RUN THE IPL**) IT WILL FLASH A FILE TO **FLASH 0** AND **FLASH 2**.
 SELECT **YES** AND THEN PRESS THE BUTTON AND THE INSTALLER WILL BACKUP SOME FILES TO **FLASH 2** AND THEN FLASH SOME FILES TO **FLASH 0**, IF NOT DONE YOU WILL NOT BE ABLE TO WRITE THE IPL TO YOUR MEMORY STICK BOOT SECTOR.
 THE SCREEN SHOULD TELL YOU THAT THE FATMS371.PRX HAS BEEN INSTALLED ON TO YOUR PSP SO PRESS TO RETURN TO THE XMB.
 PRESS AND THEN PRESS AGAIN TO RUN THE INSTALLER.
12. RUN **STAGE 1** CHOOSING TO LOAD THE DESIRED IPL (THE TIME MACHINE IPL IS ADVISED AS THIS WILL ALLOW THE BATTERY

TO BE USED AS A NORMAL ONE, FOR A SLIM YOU NEED TO BE RUNNING AT LEAST 3.90M33-2 FIRMWARE), WHEN DONE GO TO THE NEXT STAGE.

IF YOU ALREADY OWN A **PANDORA BATTERY** YOU CAN MISS **STAGE 2**, IF YOU DON'T YOU MUST RUN **STAGE 2**.

13. RUN **STAGE 2** AND SELECT THE OPTION TO BACK UP YOUR BATTERY SERIAL NUMBER TO THE MEMORY STICK IF IT IS NOT ALREADY THERE (THIS WILL BE NEEDED TO CONVERT YOUR BATTERY BACK TO NORMAL IF YOU NEEDED TO), AND THEN CONVERT YOUR BATTERY TO A PANDORA ONE AND THEN GO BACK TO THE MAIN MENU.

14. AFTER MAKING THE PANDORA BATTERY PLUG IN THE AC CABLE AND REMOVE YOUR BATTERY.

15. RUN **STAGE 3** TO INSTALL THE FIRMWARE THAT IS REQUIRED TO MAKE YOUR U.P.T. MAGIC MEMORY STICK.

IF YOU ALREADY OWN A PANDORA/U.P.M.S OR U.P.T. MEMORY STICK AND ONLY WISH TO UPGRADE SELECT THE OPTION **CLEAN MS** FOR A FRESH INSTALL OF ALL THE REQUIRED FILES BY PRESSING THE **X** BUTTON.

RUN **STAGE 3** TO INSTALL THE ALL FIRMWARE THAT YOU WILL REQUIRE TO MAKE YOUR MAGIC MEMORY STICK.

16. PRESS **X** TO EXIT THE INSTALLER.

IF YOU WISH TO ENHANCE YOU U.P.T. MAGIC MEMORY STICK YOU CAN ALWAYS RUN **STAGE 4** WHICH IS THE UTILITIES MENU AND THEN USE THIS OPTION TO DOWNLOAD ANY ADDITIONAL SOFTWARE THAT YOU FEEL YOU MAY REQUIRE.

YOU SHOULD NOW HAVE THE ULTIMATE UNBRICKER/DOWNGRADER.

THE BATTERY AND STICK COMBINATION IS NOW CAPABLE OF DOING ALL THE FOLLOWING:

1. UPGRADE A SLIM TO OFFICIAL FIRMWARE 3.71 OR CUSTOM FIRMWARE 3.71-2 M33.
2. UPGRADE A PHAT TO OFFICIAL FIRMWARE 3.71 OR CUSTOM FIRMWARE 3.71-2 M33 w/1.50-2 KERNEL PATCH.
3. UPGRADE A SLIM TO OFFICIAL FIRMWARE 3.80 OR CUSTOM FIRMWARE 3.80-5 M33.
4. UPGRADE A PHAT OFFICIAL FIRMWARE 3.80 OR CUSTOM FIRMWARE 3.80-5 M33 w/1.50 KERNEL PATCH.
5. UPGRADE A SLIM TO OFFICIAL FIRMWARE 3.90 OR CUSTOM FIRMWARE 3.90-3M33.
6. UPGRADE A PHAT TO OFFICIAL FIRMWARE 3.90 OR CUSTOM FIRMWARE 3.90-3 M33 w/1.50 KERNEL PATCH.
7. UPGRADE A SLIM TO OFFICIAL FIRMWARE 4.01 OR CUSTOM FIRMWARE 4.01-2 M33.
8. UPGRADE A PHAT TO OFFICIAL FIRMWARE 4.01 OR CUSTOM FIRMWARE 4.01-2M33 w/1.50 KERNEL PATCH.
9. START UP A **PSP** WITH ULTIMATE LOADER WITH SUPPORT FOR CHOOSING WHICH PANDORA YOU REQUIRE V3, V4, V5 OR V7 (BY HOLDING DOWN THE REQUIRED BUTTON).
10. BOOT TO THE XMB WITH THE PANDORA BATTERY INSERTED.
11. RECOVER A SOFTWARE BRICKED **PSP** (PHAT OR SLIM).

HERE IS A LIST OF WHAT EACH APPLICATION CAN DO:

DESPERTAR CEMENTERIO 7:

UPGRADE ALL **PSP** PHAT'S AND SLIM'S TO OFFICIAL FIRMWARE 4.01 OR CUSTOM FIRMWARE 4.01 M33-2

BACK UP NAND AND REINSTALL

REGENERATE IDSTORAGE

REFORMAT THE IFLASH

DESPERTAR CEMENTERIO 5:

UPGRADE ALL **PSP** PHAT'S AND SLIM'S TO OFFICIAL FIRMWARE 3.90 OR CUSTOM FIRMWARE 3.90 M33-3

BACK UP NAND & REINSTALL

DESPERTAR CEMENTERIO 4:

UPGRADE ALL **PSP** PHAT'S AND SLIM'S TO OFFICIAL FIRMWARE 3.80 OR CUSTOM FIRMWARE 3.80 M33-5

BACK UP NAND & REINSTALL

DESPERTAR CEMENTERIO 3:

UPGRADE ALL **PSP** PHAT'S AND SLIM'S TO OFFICIAL FIRMWARE 3.71 OR CUSTOM FIRMWARE 3.71M33-2

BACK UP NAND & REINSTALL

ACCESS THE USB THROUGH THE MENU.

TOOLS MENU:

LOAD JAS0NUK'S ELF MENU

NANDTOOL (USED FOR NANDBACKUPS, RESETING AND REFORMATTING YOUR LFLASH)

IDSTORAGE BACKUP (USED TO BACK UP YOUR IDSTORAGE KEYS)

EASY NAND BACKUP (USED TO BACKUP A FULL NAND IMAGE)

ULTIMATE LOADER:

THIS IS A PRX THAT WAS CREATED BY GH0ST/MAGNATEK WHICH WILL BOOT UP FIRST WHILE YOU HOLD DOWN THE LEFT TRIGGER BUTTON WHEN THE TIME MACHINE-IPL IS INSTALLED AND LET'S YOU CHOOSE WHICH MENU SYSTEM YOU WANT TO USE AND LAUNCH.

IT WILL BOOT DESPERTAR CEMENTERIO 3, 4 & 5 ON BOTH A PHAT AND SLIM PSP's.

EXTRA MEMORY STICKS.

IF YOU WISH TO USE ANY ADDITIONAL MEMORY STICKS BUT LEAVE YOUR BATTERY SET TO THE PANDORA STATE SO THAT YOU CAN LEAVE YOUR MAGIC MEMORY STICK ALONE THAT CONTAINS THE **U.P.T.** FILES ON ALL YOU HAVE TO DO IS:-

1. CONNECT TO YOUR AC SUPPLY.
2. INSERT THE MEMORY STICK YOU WISH TO USE.
3. SWITCH ON YOUR PSP.
4. FORMAT THE MEMORY STICK FROM WITH IN THE XMB.
5. GO TO THE USB ICON AND CONNECT TO THE COMPUTER.
6. OPEN UP THE PSP/GAME FOLDER AND PLACE IN THERE THE U.P.T. APPLICATION FILE (THIS JUST DRAG AND DROP).
7. DISCONNECT FROM THE COMPUTER.
8. GO TO THE GAME ICON IN THE XMB AND RUN THE INSTALLER.
9. IF YOU ARE GOING TO USE A FAKE MEMORY STICK USE THE FORMAT OPTION FROM WITHIN THE U.P.T. INSTALLER FIRST AND THEN REPLACE THE U.P.T. APPLICATION IN TO THE CORRECT FOLDER.
10. RUN STAGE 1 CHOOSING TO LOAD THE TIME MACHINE IPL, THIS WILL THEN ALLOW YOU TO USE THIS MEMORY STICK AS A NORMAL ONE WITH YOUR PANDORA BATTERY (YOU DO NOT NEED TO INSTALL ALL OF THE FILES).

CREDITS:

DEVELOPER: MAGNATEK
SUPPORTING DEVELOPER: DEATHCRADLE
GRAPHICS: EM82
MUSIC: MUZZ
TESTING: ARCHIE120
JANUARY39
MUZZ
KAROTHACKER
SPIDEY

SPECIAL THANKS TO:

TEAM M33

SILVERSPRING

JAS0NUK

MATHIEULH

CORY1492

KLUTSH

TEAM WILDCARD

AND EVERYBODY ELSE INVOLVED WITH THE HOMEBREW SCENE AND CFW.

DISCLAIMER

THE **U.P.T. TEAM** ARE GLAD THAT YOU HAVE DECIDED TO DOWNLOAD AND USE OUR SOFTWARE BUT WE ARE NOT TO BE HELD RESPONSIBLE FOR ANY DAMAGE THAT MIGHT OCCUR WHILST USING AND CREATING YOUR **U.P.T.** STICK.

FROM ALL THE U.P.T. TEAM.

HAVE FUN WITH YOUR U.P.T. MAGIC MEMORY STICK AND PLEASE HELP TO SPREAD THE WORD.

FOR SUPPORT USING U.P.T VISIT

WWW.PSP4NOOBZ.COM/FORUMS

FOR UPDATE INFORMATION VISIT

WWW.PSP4NOOBZ.COM

**(IF AN UPDATE IS AVAILABLE YOU CAN DOWNLOAD VIA YOUR PSP'S
USING THE UPDATE FEATURE FOUND IN PAGE 2 OF THE UTILITIES MENU).**

PSP4Noobz.com

